OPERATIONS CENTER



EQUIPMENT.

Add new equipment and manually adjust offsets of existing equipment.

trank i

Schlagenalyse




Operations Center -Equipment

Open Operations Center

1


2

Select "Equipment: Manage machines, implements, and technology devices." under the "Setup" menu.



Manually Adjust Offsets of Existing Equipment

3 Select current piece of equipment from equipment list.




Click "Characteristics & Offsets" from the menu that pops up in the bottom right corner.

Plan 🗸	Analyze ~ ···· More ~			New ⑦ 🌲 👪 Kingland F
its Devices	Global Search (Machine Type) (Machine	Model Pending Transfer Co	nnectivity) (Y Filters)	+ Add Sy Transfer Delete
	Machine Details 🗢	Connectivity \$	Pairings	5 7R
	Sprayer JOHN DEERE 412R	Connectivity Unavailable No Modem	***	Information Characteristics & Offsets Pa General
	Two-wheel Drive Tractors - 140 Hp And Above JOHN DEERE 7R 250	Connectivity Unavailable No Modem		Name 7R Serial Number
	Track Tractor JOHN DEERE 8RX 410	Connectivity Unavailable No Modem	3 	Model 7R 250
70	Combine JOHN DEERE \$770	Connectivity Unavailable No Modem	***	Type Two-wheel Drive Tractors - 140 Hp And Above Make JOHN DEERE

Made with Scribe - https://scribehow.com

4





		Operations Brandon L	
		New ? 4 Kingland	
		+ Add 🔄 Transfer 🗍 👔 Delete 🕞 🖪	xport
Pending Transfer	Connectivity T Filters		
ectivity 🗢	Pairings	7R 27	×
ectivity Unavailable lodem	-	Information Characteristics & Offsets Reference on Sector or Greenstar 273 papaga Reference Offset 3 for Gen 4 Displays.	Pairir >
ectivity Unavailable lodem	-	Distance	
ectivity Unavailable lodem			
ectivity Unavailable odem		Connection Offsets	^
		Connection Type	
		Rear Rigid 3-pt	<u>~</u>
		Cancel	Save

		Operations Center Brandon Ludwig ~
		New ⑦ 🌲 👪 Kingland Farms ~
		+ Add STransfer
g Transfer	Connectivity Tilters	
	Pairings	💑 7R 🛃 🗶
available		Information Characteristics & Offsets Pairir > retretence on Set D for Greenstan 2/3 Displays. Reference Offset 3 for Gen 4 Displays.
available		Distance
available		0 in 0
available		Connection Offsets
		Connection Type
		Rear Pivot Drawbar 🗸 🗸

Add New / Missing Equipment

Select the yellow "Add" button.

8

9

🚺 Plan 🗸 📊 Ana	alyze V 🚥 More V		0
s Devices			+ Add
Glob	Machine Details \$	Connectivity Tilters	Pairings
ar	Sprayer JOHN DEERE 412R	Connectivity Unavailable No Modem	
	Two-wheel Drive Tractors - 140 Hp And Above JOHN DEERE 7R 250	Connectivity Unavailable No Modem	
	Track Tractor JOHN DEERE 8RX 410	Connectivity Unavailable No Modem	
\$770	Combine JOHN DEERE S770	Connectivity Unavailable No Modem	
yer	Sprayer CASE IH PATRIOT-4440	Connectivity Unavailable No Modem	

If user has a serial number of their equipment, they can enter it in the "Serial Number" field.

Organization*	* Required
Kingland Farms - 453782 🗸 🗸	
Serial Number*	
Enter Serial Number	have a serial number
Name*	
Enter Equipment Name	
Model*	
Q Search	

If model is new enough and can utilize JDLink, user can elect to have it added to their account and removed from someone else's account. This will send a request to the owner of the org that the equipment is currently in.

HN DEERE					Operat Bran
Setup 🗸 🗿 Plan 🗸	h Analyze ~ ···· More ~		New 🕜	۰	fgt King
nt					
	Organization*	* Required			
	Kingland Farms - 453782 🗸 🗸				
	Serial Number*				
	1RW8360RCDD082752	I do not have a serial number			
	the organization you specified above. Suff Your name, organization name and addres	her organization. Use the Request Transfer button below to request it be transferred to icient access level required. ss will be visible in this request. The other organization will have 14 days to approve or sment's connectivity will be deactivated. If this request is urgent, contact your local			
	Name*				
	Enter Equipment Narve				
	8360R	Change lean			
				Can	cel Requi

Adding Equipment that doesn't have a Serial Number?

10 Check the "I do not have a serial number" box.

Drganization*	* Required
Kingland Farms - 453782 V	
Serial Number*	
No Serial Number do not have a seri	
No Serial Number	al number
Adding a serial number allows you to pair a modem and access equ	
Adding a serial number allows you to pair a modem and access equ	
Adding a serial number allows you to pair a modem and access equ	

11 Enter a name for the piece of equipment the user wishes to add.

Organization*		* Required
Kingland Farms - 453782 🗸		
Serial Number*		
No Serial Number	l do not have a serial number	
Adding a serial number allows you to pair a mod		
Adding a serial number allows you to pair a mod Name* Enter Equipment Name		
Adding a serial number allows you to pair a mod		

12 Enter a model into the "Model" field and then select the desired model.

No Serial Number	×	I do not have a serial n	umber	
Adding a serial number allo	ws you to pair a mode	m and access equipme	nt specific information.	
Name*				
s780				
Model*	1			
Q \$780	×			
Make Type Categ	gory			
Model	Make	Туре		
() * 5780	JOHN DEERE	Combine		
O	JOHN DEERE	Combine		
Add Custom Model				
Add Custom Model				

13 When finished, select "Add Equipment" on the bottom right of the screen.